



Address: 8 Manburgh Terrace
Darra Qld. 4076
Postal Address: P.O. Box 3045
Darra Qld. 4076
Phone: +61 (7) 3375 3199
Facsimile: +61 (7) 3375 3886
E-mail: info@luxurypaints.com.au

Date Issued: 23 September, 2009

SPEEDPREP SEALER PRIMER UNDERCOAT

Product Line: 21

Product Code: 2101, 2102, 2104; 2110; 2120.

Australian Paint Approval Scheme: 0172, 0163/1, 0163/2, 0183 (formerly GPC-S-17/2, GPC-U-163/1, GPC-U-163/2, GPC-P-18/3).

Description

Speedprep Sealer Primer Undercoat is a water-based sealer/ primer/ undercoat designed to be used on interior and exterior timber, plasterboard, fibro, fibrous plaster, masonry, cement, etc.

Speedprep Sealer Primer Undercoat can be recoated with either water-based or solvent-based paints. Drying and recoating times are 30 minutes and 2 hours respectively for water based systems under good drying conditions. It is suggested to allow 4 hours drying for top coating with solvent based coatings. Do not apply when temperature is below 12°C or when humidity is excessive.

Speedprep Sealer Primer Undercoat can be tinted using Luxury Machine Colorants to a range of pastel colours

Spreading rate is approximately 12 square metres per litre depending on application (brush, roller or spray), weather conditions and the surface material. Speedprep Sealer Primer Undercoat has no roller splatter or spray and is non-toxic and lead-free.

Surface Preparation

All surfaces must be dry, well prepared and free from dirt, oil, grease and other contaminants.

New Plasterboard/Timber/Brick/Masonry

Fill any holes with suitable filler following the manufacturer's directions. Sand surfaces smooth, remove all dust, grease and dirt. Apply one coat of Speedprep Sealer Primer Undercoat.

Previously Painted Surfaces

Remove all loose and flaking paint with a wire brush or scraper. Ensure old paint has good adhesion to the substrate. Gloss enamel surfaces must be first sanded to a dull finish to obtain good inter-coat adhesion.

Application Method

Stir contents of can thoroughly with a wide flat stirrer ensuring the bottom of the can is reached. Apply 1 full coat of Speedprep Sealer Primer Undercoat by brush, roller or spray.

Do not apply Speedprep Sealer Primer Undercoat below 12°C or is likely to fall below 12°C before the paint can through dry.

Brush/Roller

Pre-wet brushes and rollers. Flow paint generously and spread evenly - do not overspread. Use a quality bristle brush or a medium 12mm-nap roller cover for best results. On rough surfaces, use a 20mm-nap roller cover. Avoid excessive brushing or rolling.

Spray

Suitable for application using standard spray equipment. If necessary, Speedprep Sealer Primer Undercoat may be thinned sparingly with up to 100mls of water per litre of paint to help atomization.

Thinning

Not usually required, however it may be thinned sparingly with water.



Address: 8 Manburgh Terrace
Darra Qld. 4076
Postal Address: P.O. Box 3045
Darra Qld. 4076
Phone: +61 (7) 3375 3199
Facsimile: +61 (7) 3375 3886
E-mail: info@luxurypaints.com.au

Date Issued: 23 September, 2009

Approximate Coverage

Covers approximately 12 -14 square metres per litre depending on the surface porosity.

Colours Available

Available in white which may be tinted to pastel colours.

Drying Times

Approximate drying times at 25°C and 50% Relative Humidity.

Touch Dries:	30 minutes
Recoat:	Minimum 2 hours.

Drying Times may be extended by adverse drying conditions or very high film build.

Cleanup

Clean all equipment promptly in water.

Properties

SOLIDS BY VOLUME:	34%
SOLIDS BY WEIGHT:	53%
WEIGHT PER LITRE:	1.4kg
GLOSS LEVEL:	Low sheen
VOC:	approximately 45 grams per litre

Resistance Properties

ABRASION:	N/A
HEAT:	Up to 60°C
SOLVENT:	Fair. Coating is a little sensitive to some solvents.
WATER/STEAM:	Fair. Resists mild exposure to steam and condensation.
WEATHER:	Interior/exterior use - excellent when top coated.

Additional Information

To achieve a very smooth finish, lightly sand Speedprep Sealer Primer Undercoat before top coating.

On very old exterior timber which has suffered from extensive degradation such as on old Queenslander type homes, it is recommended to use Multipurpose Undercoat mixed with a little pale boiled linseed oil to help nourish the timber.